

Ferrari 360 HVAC panel Disassembly:

Tools Needed:

- Retaining ring pliers
- Phillips screwdriver
- Silicone

Step 1: Set both top push buttons in the outward/OFF position and turn the knobs either full left or right. (To help with reassembly.)

Step 2: Remove the one rear (Phillips) screw from the back of the panel and gently slide the back cover off.

Step 3: Gently remove the electronics panel from the faceplate. It may seem tight—use a bit of force if needed.



Step 4: Flip over the faceplate and remove the three C-clips from the knob tabs.

Step 5: After the C-clips are removed, gently squeeze the four tabs on the rear of each knob and push them through toward the front. The little tabs often break and fall apart—so don't be alarmed if they are damaged.

Now the panel is completely disassembled.

Note: Sometimes the little green sleeves on the button lights slide off and stay up in the button. Use a small pair tweezers and grab it and slide back onto the light on the panel if this happens.

Reassembly:

Note: You will not need the C-clips or old knobs.

Step 1: Carefully slide the electronics board back onto the faceplate. Make sure the little green sleeved lights line up and slide into the upper two button holes. Install the rear cover and screw back together.

Step 2: Add a small amount of clear silicone to each knob shaft. Slide each knob down into place. Push firmly to seat them completely.

Step 3: Set panel aside for a few hours to let the silicone set.

Step 4: Reinstall in the car.

