

S**N****N****M** **StickyNoMore** **Removal Instructions**

Ferrari F355 Convertible Handle



Tools needed:
Metal Hammer
3/16" Flat Punch
Screwdriver / Pry Bar



- Note: to avoid damaging the windshield please begin with the convertible top lowered.



- The handle is attached to a splined shaft with a small pin. (Pin part# 63990900)
Carefully place a punch on the end of the pin recessed slightly into the handle.
(IMPORTANT: the pin only slides out in one direction. It must be pushed out from the side slightly recessed and facing the back of the car with the convertible top up.)
Because the pin is pressed in, it will take several sharp taps with a hammer to get it to begin moving. Once the pin is halfway out, gently pull it the rest of the way.



- With the pin removed, gently pry the handle off the shaft with a screwdriver. Use caution to avoid getting sticky residue from the handle on the interior of the car.

Good luck, be patient and if you have any questions please do not hesitate to call or email us. Thanks